(drawn to scale) 4" 1 1/2" 1/4" © madebyalan.com 1 1/4" 1/4" 1 1/8" 1 1/8" 6 1/4" 1/4" Rip 2x4 to give 1 1/4" wide section. Rip again twice for two 1/4" thick pieces. Custom fit From the 1 1/4" wide piece crosscut 6 1/4" for the body, 2 1/4" for cab, 1 1/2" for hood. Lightly sand all edges. Use the rounded edge of the 2x4 for front of bed top of hood, back of cab, bottom of body. Drill two 7/32" axel holes through body first. Then attach cab and hood to body using wood glue. Take the 1/4" slices and rip from 1 1/2" down to 1 1/4". After cutting off rough ends cut four 4" pieces two for floor and two for sides. Center the two 2 1/2" floor pieces on body, attach sides, custom fit front of bed. Rear View Alan 1 1/2"